

RK3 Designs

Updated recipe as of 9/15/21

To determine how much UTC needed use the following calculations for **BOTH** the **Natural & Gloss Finish**

Length (in.) x Width (in) = Sq. inches

Divide by 144 = Sq. Feet

Project Sq. Ft. x .275 = Amount of UTC needed

I round up to the next increment on the cup for easy calculation of 2:1 ratio

Ultimate Top Coat – Natural Matte Finish

2:1 Ratio of parts A&B then add

.5 oz. of water per 3 oz. UTC

or

.16 oz. of water X each oz. of UTC

(Make sure you mix A&B together first before adding water)

(Hint: 2 capful of water = 15 ml or ½ oz.)

*This mixture give you a satin matte finish allowing all the fine detail to still be seen in your design

We also tried (by accident) and had GREAT success with the ratio below, however PLEASE try this on a sample board BEFORE you jump into your project. This worked in or environment and climate. Finish came out incredibly smooth to the touch.

3:1 Ratio of parts A&B then add

.5 oz. of water per 3 oz. UTC

or

.16 oz. of water X each oz. of UTC

(Make sure you mix A&B together first before adding water)

(Hint: 2 capful of water = 15 ml or ½ oz.)

*This mixture will give you a true flat matte finish yet still be able to see all the detail in your design

Ultimate Top Coat – High Gloss

2:1 Ratio of parts A&B then add

.5 oz of water for every 1 oz. of UTC

(Make sure you mix A&B together first before adding water)

(Hint: 2 capful of water = 15 ml or ½ oz.)

Helpful Hints:

- Use ¼ nap rollers ONLY. A higher nap will cause more texture
- Use the 6 in. mini rollers, not the larger rollers. Rollers are available at most big box stores or on my website www.RK3Designs.com
- Prep rollers before starting by running them over tape to remove fuzz.
- Prep 2 dry rollers for every 1 roller
- Line your paint tray with Press N Seal for easy clean up
- Mixing cups can be washed, but throw rollers away
- You have a short working time of 15 minutes. As soon as Part A and B are mixed, you're on the clock
- To avoid lap lines, apply PLENTY of material on the surface so you have adequate material to back roll.
- I have several videos on my YouTube channel that help with the application of UTC.
- Don't hesitate to reach out if you need extra help. Our studio phone number is 830-745-3440. Leave a message and someone will call you back as soon as we can.